FGTL Docket #: 81070759
Title: METHOD AND APPARATUS FOR
CONTROLLING A TRANSFER
CASE CLUTCH TO IMPROVE VEHICLE
HANDELING

HANDELING
Applicants: Rodrigues et al
Page 1 of 8




Figure 1

FGTL Docket #: 81070759
Title: METHOD AND APPARATUS FOR CONTROLLING A TRANSFER CASE CLUTCH TO IMPROVE VEHICLE

HANDELING Applicants: Rodrigues et al

Page 2 of 8

2/8





Figure 2A

FGTL Docket #: 81070759
Title: METHOD AND APPARATUS FOR CONTROLLING A TRANSFER CASE CLUTCH TO IMPROVE VEHICLE

HANDELING Applicants: Rodrigues et al Page 3 of 8

3/8




FGTL Docket #: 81070759
Title: METHOD AND APPARATUS FOR
CONTROLLING A TRANSFER

CASE CLUTCH TO IMPROVE VEHICLE HANDELING


Applicants: Rodrigues et al Page 4 of 8

4/8










FGTL Docket #: 81070759

Title: METHOD AND APPARATUS FOR CONTROLLING A TRANSFER CASE CLUTCH TO IMPROVE VEHICLE

HANDELING Applicants: Rodrigues et al

Page 6 of 8

6/8



(Do slip + pre-emptive + handling mode) traction

Increment slip\_ctr counter

Err = delta\_wheel\_spd-fn(veh\_spd).

kp,ki = fn(throttle,veh\_spd)n\* fn(err).

kc = fn (delta\_wheel\_spd)


- TP based pre-emptive duty cycle.
   dc\_pps = fn(veh\_spd, throttle) \* fn(slip\_ctr).
  - 2. Handling duty cycle.
  - 3. PI close loop duty cycle. dc\_cl = (err \* kp + err + ki) \* kc
- 4. TP rate based pre\_emptive duty cycle. dc\_pre = fn(throttle rate, veh\_spd). hold dc\_pre constant for a while and then decrement every loop.
- 5. Total command duty cycle.

  dc\_cmd = greater of (dc\_pps, dc\_hndl)
  + dc\_cl + dc\_pre.

## Figure 4B

FGTL Docket #: 81070759
Title: METHOD AND APPARATUS FOR
CONTROLLING A TRANSFER
CASE CLUTCH TO IMPROVE VEHICLE

HANDELING
Applicants: Rodrigues et al
Page 7 of 8



FGTL Docket #: 81070759

Title: METHOD AND APPARATUS FOR CONTROLLING A TRANSFER CASE CLUTCH TO IMPROVE VEHICLE

HANDELING Applicants: Rodrigues et al

Page 8 of 8

8/8

